

## SCUBAJET

## **Installation instructions of Front Mount DHC**



1. Place all items, shown in image 1, for Front Mount DHC installation in front of you.







2. Mount the two handlebars to the DHC using the four small screws and the smaller Allen key (either bar can serve as left or right.)







3. Position the short rail on top of the large rail on the tube, aligning the edges, and secure it with two screws using the larger Allen key.

## SCUBAJET

## **Installation instructions of Front Mount DHC**







4. Slide the DHC onto the short rail, ensuring it sits just before the large screw at the front. Secure the DHC with its screw by pressing down and turning in the correct direction.







5. Attach the BT-Link to the SSC Plate by pushing it until you hear a "click" sound.







6. Secure the cable by creating a loop under the DHC and mounting it with cable clamps along the tube, maintaining consistent distances between the screws.